




Mechanical Replacement Wear Parts



LISTED BY MODEL NUMBER

DISCLAIMER

All part number information in these catalogs is for reference only. Prior to ordering, please provide your DSI/Dynamatic® representative with model, part and serial/pro number for verification.

DSI/Dynamatic® is not responsible for incorrect orders if this information is not provided.

Application Engineering ✧ Quality Products ✧ Total Solution

Terms and Conditions

All prices and discounts are subject to change without notice. Distributors and sales offices will be notified when they occur. All orders accepted by DSI/Dynamatic® are subject to the STANDARD TERMS AND CONDITIONS OF SALE found in this catalog.

WARNING:

The installation and use of Dynamatic® products should be in accordance with the provisions of the U.S. National Electric Code and/or other local codes or industry standards that are pertinent to the particular end use. Installation or use not in accordance with these codes and standards could be hazardous to personnel and/or equipment.

IMPORTANT!

If you do not find the part number you require in this catalog, please contact DSI/Dynamatic® for pricing and availability. DSI/Dynamatic® is committed to supporting all Dynamatic® Eddy Current Adjusto-Spede® products in the market place.

DISCLAIMER

All part number information in these catalogs is for reference only. Prior to ordering, please provide your DSI/Dynamatic® representative with model, part and serial/pro number for verification.

DSI/Dynamatic® is not responsible for incorrect orders if this information is not provided.

STANDARD TERMS AND CONDITIONS OF SALE

1. PRICE BOOKS

Price books are intended only as sources of general information. They are not to be construed as quotations or as representations that products described therein are available, or will be made available for immediate delivery.

2. QUOTATIONS

Seller may make quotations verbally or in writing. Verbal quotations shall expire automatically unless Seller receives Buyer's purchase order number on the day the quotation is made. Written quotations shall expire automatically unless Seller receives Buyer's written purchase order within 15 days after the date appearing on the quotation. No quotation is to operate as an offer to sell but only as a description of products. Accordingly, even prior to its expiration date, any quotation is subject to change by Seller at any time upon verbal or written notice to Buyer. All quotations are deemed to incorporate Seller's Standard Terms and Conditions of Sale.

3. ACCEPTANCE OF PURCHASE ORDERS.

Notwithstanding any contrary language contained in Buyer's purchase order, each purchase order shall be subject to acceptance by an authorized employee of Seller's plant, and each purchase and sale transaction shall be governed exclusively by these Standard Terms and Conditions of Sale. Seller reserves the right at any time before delivery and payment to correct clerical, stenographic or other errors in quotations, purchase orders or acknowledgments.

4. PRICE POLICY

Regardless of prices set forth in quotations, acknowledgments or elsewhere, Buyer shall pay a purchase price as follows:

- (a) For the following products: Fractional Horsepower Adjusto-Spede®, AC Motors, renewal parts and service, Buyer shall pay Seller's published prices in effect on the date when shipment is made or service performed.
- (b) For all other products, Buyer shall pay a purchase price equal to the smaller of: (a) Seller's published prices in effect on the date when shipment is made or (b) the prices set forth in Seller's acknowledgment increased by 1% for each month or fraction thereof that elapses between the date when the acknowledgment is mailed from Seller's factory to Buyer (designated as the "Issue Date" on the acknowledgment) and the date when shipment is made or the date for which shipment was originally scheduled (as stated on the acknowledgment) by Seller, whichever occurs sooner. However, in the event that shipment is originally scheduled to occur in excess of 12 months after Issue Date, Buyer shall pay Seller's published prices in effect on the date when shipment is made; and in any case where shipment is delayed beyond Seller's originally scheduled date for shipment by Buyer's actions or at Buyer's request, Buyer shall pay escalation charges based on the revised delivery schedule.

5. MINIMUM BILLING

The minimum billing for each purchase order shall be \$100.00 net.

6. TAXES

Any and all sales, use, personal property or other excise taxes which the Seller may be required to pay or collect, including first destination taxes, will be added to each invoice and shall be payable by Buyer on the same terms as the purchase price unless the Buyer has furnished the Seller a tax exemption certificate acceptable to the taxing authority.

7. PAYMENT TERMS

Payment terms shall be net 30 days except for International

orders, which will be cash in advance. However, on orders of \$100,000.00 or more and having delivery schedule 6 months or longer from date of order, the payment terms shall be as specified by Seller at time of quotation.

8. SHIPPING TERMS

Except as otherwise agreed, Seller shall be entitled to select carrier and make delivery in more than one shipment, in which event Buyer shall pay separately for each partial shipment.

All shipments shall be made F.O.B. point of shipment. Seller shall prepay freight (UPS shipments only), which shall be billed to Buyer as a separate item on the product invoice at Seller's standard rates applicable to the destination, or at Buyer's option, shipment shall be made freight collect. All truck shipments shall be made freight collect, unless otherwise agreed.

9. PACKAGING

At no additional charge, all products shall be packaged for domestic shipment in accordance with Seller's standard specifications. Additional charge shall be made if Buyer specifies special domestic packaging, packaging in accordance with government or military standards, overseas packaging or other special packaging. Refer to Seller's plant, nearest sales office or representative for further information.

10. TITLE AND RISK OF LOSS

Risk of loss in transit shall be borne entirely by Buyer at all times after the products are delivered to the carrier for shipment. However, title to the products and right to stop delivery in transit shall remain with Seller until Seller receives payment in full.

11. DELAYS OR DEFAULT IN DELIVERY

Seller shall have no liability to Buyer, and Buyer shall not be entitled to cancel any purchase order, for Seller's delay or default in delivery due to strikes, secondary boycotts, riots, wars, accidents, fires, floods, explosions, vandalism, government embargoes, priorities or regulations, shortages of labor, fuel, materials, supplies, power or transportation facilities, or other similar or dissimilar causes beyond Seller's reasonable control. Under no circumstances shall Seller have any liability for penalties or consequential damages of any kind resulting in whole or in part from Seller's delay in delivering, or failure to deliver, any products ordered by Buyer.

12. CHANGES TO ORDERS IN PROCESS

There shall be a charge for any and all changes in specification after an order is in process, based on the status of the order at the time the change is made. The additional charge shall be a minimum of \$50 net per item when engineering has not been started or is not required and a minimum of \$100 net per item when re-engineering is required. The additional charge shall be in addition to any change in the price of the product resulting from the change in specification. The order "Issue Date" will be moved forward to the date of the change and shipment will be rescheduled in accordance with the then current lead times. Buyer shall pay escalation charges based on the new "Issue Date" and scheduled shipping date as defined in paragraph B.

13. CANCELLATION

After Seller accepts Buyer's purchase order by faxing Seller's written acknowledgment, Buyer's cancellation of any order or portion thereof may be accomplished only upon (i) Seller's receipt of written cancellation notice at Seller's plant (cancellation notice by telephone will be deemed only as authorization for Seller temporarily to suspend performance on Buyer's order pending written confirmation of cancellation) and ii) Buyer's payment of the following cancellation charges:

Notwithstanding anything to the contrary contained herein, the minimum cancellation charges for products shall be 50% per line item or 50% per complete order.

With respect to all costs and expenses described above, Seller shall provide such substantiating documentation as Buyer may reasonably request, and Seller's computations, thus documented, shall be conclusive and binding between the parties. With respect to all canceled products, materials and supplies described above, Seller shall, upon payment of the applicable cancellation charges, make such disposition as Buyer may specify in writing within 30 calendar days after Seller notifies Buyer of the applicable cancellation charges. Buyer's failure to so specify within said 30-day period shall constitute Buyer's authorization for Seller to make such disposition as Seller chooses with no further obligation to Buyer.

14. PATENT INFRINGEMENT

With respect to all products manufactured to Buyer's design, Buyer shall indemnify and hold Seller harmless from and against any and all loss, cost, expense, claims, demands, suits and judgments resulting from actual or alleged patent infringements. With respect to all other products sold by Seller, Seller shall defend any suit or proceeding brought against Buyer on a claim that such a product, or any part thereof when employed in the manner intended by Seller, infringes any U.S. patent, provided that Seller is notified promptly in writing and given all necessary information, assistance and authority to defend same. Seller shall pay all damages and costs awarded against Buyer as a result thereof. If the court finds such an infringement, and the use of any product, in the manner intended by Seller is enjoined, Seller shall at its sole expense, at Buyer's option (a) procure for Buyer the right to continue using said product, (b) replace said product with a non-infringing product, (c) modify said product so that it becomes non-infringing or (d) remove said product and refund its purchase price and transportation and installation costs.

Seller shall have no further liability for actual or alleged patent infringement except as provided herein.

15. PRODUCT WARRANTY AND DISCLAIMER

Seller warrants to Buyer, subject to the limitations, conditions and disclaimers stated herein, that all new products manufactured by Seller shall be free from defect in material and workmanship and shall deliver their rated output as indicated on the nameplates for a period of three years from the date of shipment to the Buyer, except certain specific products as otherwise noted in the product literature.

Buyer must notify Seller in writing of defect or failure to deliver rated output within the applicable warranty period and give Seller the opportunity to determine that the defect or failure exists. Buyer shall, at Buyer's expense, make each allegedly defective product available for Seller's inspection at Buyer's place of business or, at Seller's option, return each such product to Seller's plant or service center as designated by Seller, freight both ways to be paid by Buyer. No products shall be returned to Seller's plant or service center except in accordance with Seller's prior written instructions.

To remedy the defect, the Seller may at its option, repair, rebuild or replace the defective component or complete product, using new or remanufactured components or complete product. In any case the repaired, rebuilt or replaced product shall be warranted hereunder for the then non-expired portion of the original warranty period.

Seller's sole obligation to Buyer, and Buyer's sole remedy against Seller, for any breach of this warranty shall be Seller's obligation to repair or replace the product as provided herein or, at Seller's option, to repay, upon return of the defective product, the price paid for such product by Buyer.

Products sold by Seller, but not manufactured by Seller, shall be warranted as to defects in material and workmanship consistent with the warranty policy of the original manufacturer of the products.

In no event shall Seller have any liability for incidental or consequential damages of any kind resulting from a breach of this warranty. THIS WARRANTY IS EXCLUSIVE AND IS GIVEN IN LIEU OF ALL OTHER WARRANTIES, EITHER EXPRESSED OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY FOR MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

16. RETURNS

No products shall be returned to Seller, whether for inspection, repair, replacement or any other reason, without prior written consent from Seller's plant, sales office or representative.

MODEL	PART NUMBER	DESCRIPTION	
AS-14	000-081022-0100	END COVER, AS-14	
	000-081097-0045	COIL, AS-14, 45V	
	000-081097-0090	COIL, AS-14, 90V	
	000-081258-0100	GENERATOR ROTOR, AS 14-18	
	000-081364-0100	GENERATOR FIELD KIT	
	0DY-012646-0000	BALL BEARING, W/ONE SEAL, 305	
	0DY-013193-0000	BALL BEARING, W/ONE SEAL, 208	
	0DY-013282-0000	BALL BEARING, W/ONE SHIELD, 206	
	0DY-015784-0000	WAVE SPRING, 3.12 O.D. X 2.73 I.D.	
	0DY-016398-0000	OIL SEAL, 40 MM DIA. SHAFT	
	0DY-016449-0000	BALL BEARING, SR, ONE SHIELD, 6306	
	AS-18	0DY-016449-0000	BALL BEARING, SR, ONE SHIELD, 6306
		0DY-007273-0000	BALL BEARING, SR, W/ONE SEAL, 211
0DY-013266-0000		BALL BEARING, SR, W/ONE SHIELD, 207	
0DY-011332-0000		BALL BEARING, SR, W/ONE SHIELD, 306	
000-082097-0045		COIL, AS-18, 45V	
000-082097-0090		COIL, AS-18, 90V	
000-082022-0200		END COVER, AS-18-25	
000-081364-0100		GENERATOR FIELD KIT	
000-081258-0100		GENERATOR ROTOR, AS 14-18	
0DY-016400-0000		OIL SEAL, 45 MM DIA. SHAFT	
0DY-016512-0000		RETAINING WASHER	
0DY-016588-0000		WAVE SPRING, 3.87 O.D. X 3.37 I.D.	
AS-21		0DY-007273-0000	BALL BEARING, SR, W/ONE SEAL, 211
	0DY-007336-0000	BALL BEARING, SR, W/ONE SEAL, 307	
	0DY-015621-0000	BALL BEARING, SR, W/ONE SHIELD, 309	
	0DY-003634-0000	BALL BEARING, W/ONE SHIELD, 209	
	000-083097-0045	COIL, AS-21, 45V	
	000-083097-0090	COIL, AS-21, 90V	
	000-082022-0200	END COVER, AS-18-25	
	000-081364-0100	GENERATOR FIELD KIT	
	000-083258-0100	GENERATOR ROTOR, AS-21/25	
	0DY-016402-0000	OIL SEAL, 55 MM DIA. SHAFT	
	0DY-016588-0000	WAVE SPRING, 3.87 O.D. X 3.37 I.D.	
	AS-25	0DY-009263-0000	BALL BEARING, SR, W/ONE SEAL, 212
		0DY-013574-0000	BALL BEARING, SR, W/ONE SHIELD, 210
0DY-010237-0000		BALL BEARING, SR, W/ONE SHIELD, 309	
0DY-015621-0000		BALL BEARING, SR, W/ONE SHIELD, 309	
000-084499-0045		COIL, AS-25, 45V	
000-084499-0090		COIL, AS-25, 90V	
000-082022-0200		END COVER, AS-18-25	
000-081364-0100		GENERATOR FIELD KIT	
000-083258-0100		GENERATOR ROTOR, AS-21/25	
0DY-016471-0000		OIL SEAL, 62 MM DIA. SHAFT	
0DY-016589-0000		WAVE SPRING, 4.25 O.D. X 3.74 I.D.	
AS-27		0DY-016731-0000	BALL BEARING, SR, 213
		0DY-016729-0000	BALL BEARING, SR, 311
	0DY-016723-0000	BALL BEARING, W/2 SEALS, 6217	
	0DY-016738-0000	BEARING, SPHERICAL ROLLER, 21311	
	000-091046-0045	COIL, AS-27, 45V	
	000-091046-0090	COIL, AS-27, 90V	
	000-091047-0100	END COVER, AS-27	
	000-091081-0100	GENERATOR FIELD ASSY, AS-27	
	000-091061-0100	GENERATOR ROTOR, AS-27	
	0DY-016635-0000	OIL SEAL, 90 MM DIA. SHAFT	
	0DY-016718-0000	WAVE SPRING, 120 MM O.D.	
	0DY-016720-0000	WAVE SPRING, 5.87 O.D.	

MODEL	PART NUMBER	DESCRIPTION
AT-14	000-081258-0100	GENERATOR ROTOR, AS 14-18
	000-081364-0100	GENERATOR FIELD KIT
	000-081389-0100	SHAFT, AT-14
	000-081412-0045	COIL, AT-14, 45V
	000-081412-0090	COIL, AT-14, 90V
	000-081449-0100	DUST BAFFLE KIT, AT-14
	000-084379-0100	AIR OUTLET GRILL, AT-14
	0DY-016449-0000	BALL BEARING, SR, ONE SHEILD, 6306
	0DY-016770-0000	BALL BEARING, SR, ONE SHEILD, 203
	0DY-016789-0000	OIL SEAL, 22 MM DIA. SHAFT
	0DY-016791-0000	WAVE SPRING, 40MM O.D.
	0DY-016796-0000	JUNCTION BOX W/NEOPRENE GASKET
	AT-18	000-081258-0100
000-081364-0100		GENERATOR FIELD KIT
000-082389-0100		SHAFT, AT-18
000-082412-0045		COIL, AT-18, 45V
000-082412-0090		COIL, AT-18, 90V
000-082449-0100		DUST BAFFLE KIT, AT-18
000-084379-0200		AIR OUTLET GRILL, AT-18
0DY-016449-0000		BALL BEARING, SR, ONE SHEILD, 6306
0DY-016769-0000		BALL BEARING, SR, ONE SHEILD, 205
0DY-016790-0000		OIL SEAL, 30 MM DIA. SHAFT
0DY-016792-0000		WAVE SPRING, 52MM O.D.
0DY-016796-0000		JUNCTION BOX W/NEOPRENE GASKET
AT-21		000-081364-0100
	000-083258-0100	GENERATOR ROTOR, AS 21/25
	000-083389-0100	SHAFT, AT-21
	000-083412-0045	COIL, AT-21, 45V
	000-083412-0090	COIL, AT-21, 90V
	000-083449-0100	DUST BAFFLE KIT, AT-21
	000-084379-0300	AIR OUTLET GRILL, AT-21
	0DY-015621-0000	BALL BEARING, SR, W/ONE SHIELD, 309
	0DY-016398-0000	OIL SEAL, 40 MM DIA. SHAFT
	0DY-016768-0000	BALL BEARING, SR, ONE SHEILD, 206
	0DY-016795-0000	WAVE SPRING, 62MM O.D.
	0DY-016796-0000	JUNCTION BOX W/NEOPRENE GASKET
	AT-25	000-081364-0100
000-083258-0100		GENERATOR ROTOR, AS 21/25
000-084379-0400		AIR OUTLET GRILL, AT-25
000-084490-0100		SHAFT, AT-25
000-084493-0045		COIL, AT-25, 45V
000-084493-0090		COIL, AT-25, 90V
0DY-015621-0000		BALL BEARING, SR, W/ONE SHIELD, 309
0DY-016747-0000		BALL BEARING, SR, ONE SHEILD, 207
0DY-016783-0000		WAVE SPRING, 72MM O.D.
0DY-016796-0000		JUNCTION BOX W/NEOPRENE GASKET
0DY-016400-0000		OIL SEAL, 45 MM DIA. SHAFT
AT-280	000-084379-0500	AIR OUTLET GRILL, AT-28
	000-091061-0100	GENERATOR ROTOR, AS-27
	000-091081-0100	GENERATOR FIELD ASSY, AS-27
	000-091158-0100	SHAFT, AT-280
	000-091167-0045	COIL, AT-280, 45V
	000-091167-0090	COIL, AT-280, 90V
	000-091232-0100	DUST BAFFLE KIT, AT-28
	0DY-016402-0000	OIL SEAL, 55 MM DIA. SHAFT
	0DY-016729-0000	BALL BEARING, SR, 311
	0DY-016738-0000	BEARING, SPHERICAL ROLLER, 21311
	0DY-016739-0000	WAVE SPRING, 85MM O.D.

MODEL	PART NUMBER	DESCRIPTION
AT-280	0DY-016763-0000	BALL BEARING, SR, W/ONE SHIELD, 209
	0DY-016796-0000	JUNCTION BOX W/NEOPRENE GASKET
AT-320	000-027379-0100	BRAKE ROTOR
	000-078528-0100	DISCHARGE GRILLE, AT-320
	000-085010-0100	DISCHARGE GRILLE, AT-320
	000-092111-0045	COIL, AT-320, 45V
	000-092111-0090	COIL, AT-320, 90V
	000-092167-0100	GENERATOR ROTOR, AT-320
	000-092181-0100	SHAFT, AT-320
	000-092194-0100	GENERATOR FIELD ASSY, AT-320
	000-092201-0200	SHAFT, AT-320, SPECIAL LENGTH
	0DY-007377-0000	BALL BEARING, SR, W/ONE SHIELD, 313
	0DY-015621-0000	BALL BEARING, SR, W/ONE SHIELD, 309
	0DY-016757-0000	WAVE SPRING, 100MM O.D.
	0DY-016796-0000	JUNCTION BOX W/NEOPRENE GASKET
	0DY-016810-0000	OIL SEAL, 65 MM DIA. SHAFT
0DY-016826-0000	BEARING, SPHERICAL ROLLER, 21313	
AT-360	000-027379-0100	BRAKE ROTOR
	000-078602-0100	DISCHARGE GRILLE, AT-360
	000-087102-0100	GENERATOR ROTOR, AT-360
	000-093111-0045	COIL, AT-360, 45V
	000-093111-0090	COIL, AT-360, 90V
	000-093181-0100	SHAFT, AT-360,
	000-093182-0100	GENERATOR FIELD ASSY, AT-360
	000-093201-0200	SHAFT, AT-360, SPECIAL LENGTH
	000-094182-0100	GENERATOR FIELD ASSY, AT-360
	0DY-005001-0000	BALL BEARING, SR, W/ONE SHIELD, 316
	0DY-016718-0000	WAVE SPRING, 120 MM O.D.
	0DY-016729-0000	BALL BEARING, SR, 311
	0DY-016796-0000	JUNCTION BOX W/NEOPRENE GASKET
	0DY-016822-0000	OIL SEAL, 80 MM DIA. SHAFT
0DY-016845-0000	BEARING, SPHERICAL ROLLER21316	
AT-440	000-078667-0100	DISCHARGE GRILLE, AT-440
	000-094111-0045	COIL, AT-440, 45V
	000-094111-0090	COIL, AT-440, 90V
	000-094167-0100	GENERATOR ROTOR, AT-440
	000-094181-0100	SHAFT, AT-440
	000-094182-0100	GENERATOR FIELD ASSY, AT-440
	0DY-007377-0000	BALL BEARING, SR, W/ONE SHIELD, 313
	0DY-016796-0000	JUNCTION BOX W/NEOPRENE GASKET
	0DY-016816-0000	WAVE SPRING, 140MM O.D.
	0DY-016823-0000	OIL SEAL, 100 MM DIA. SHAFT
	0DY-016840-0000	BEARING, SPHERICAL ROLLER, 21318
FAS	000-150170-0001	BRUSH HOLDER CAP (OLD STYLE "SQUARE")
	000-150170-0002	BRUSH HOLDER (OLD STYLE "SQUARE")
	000-150170-0003	
	000-150170-0010	
	000-150171-0100	BRUSH (OLD STYLE "SQUARE")
	000-150171-0200	BRUSH (NEW STYLE "RECTANGULAR")
	000-151327-0100	BASE, FAS, GEAR W/SPECIAL SLOTS
	000-151627-0100	GENERATOR ROTOR, W/KEYWAY
	000-151627-0200	GENERATOR ROTOR, W/O KEYWAY
	000-152655-0100	SHAFT PROTECTOR
	000-160608-0100	END BRACKET & GENERATOR ASSY
	009-160590-0100	SHAFT, FAS
	009-160592-0100	JUNCTION BOX
	009-160606-0100	JUNCTION BOX COVER
009-160607-0100	END BRACKET BRUSH HOLDER ASSY	

MODEL	PART NUMBER	DESCRIPTION	
FAS CONT'D.	009-160609-0100	END BRACKET BOLT	
	009-160610-0100	SLIP RING ASSY	
	009-160611-0100	GENERATOR FIELD ASSY, FAS	
	009-160614-0040	COIL, FAS, 40V	
	009-160624-0100	FIELD & SHAFT ASSY	
	009-160652-0200	END BRACKET, W/G-2 GENERATOR	
	009-160679-0100	HARDWARE KIT, FAS	
	0DY-005359-0000	PLUG BUTTON, FOR 7/8"DIA.HOLE	
	0DY-009103-0000	SPRING, STANDARD ADJUSTABLE OR LOAD	
	0DY-010187-0000	BALL BEARING, SR, W/2 SEALS, 203	
	0DY-010188-0000	RETAINING RING, EXTERNAL, SELF-LOCK	
	0DY-012569-0000	CLIP, TINNEMAN SPEED	
	0DY-012575-0000	CLIP, TINNEMAN SPEED	
	0DY-013440-0000	BALL BEARING, SR, W/2 SEALS, 204 SPL.	
	0DY-013441-0000	BALL BEARING, SR, W/2 SEALS, 203	
	0DY-016326-0000	TOLERANCE RING	
	0DY-016343-0000	TOLERANCE RING	
	0DY-016346-0000	TOLERANCE RING	
	AS-703	000-018973-0000	ACTUATOR SPRING
		000-032295-0000	SHAFT, AS-703
000-032296-0000		BRAKE FAN	
000-032297-0000		BRAKE ROTOR	
000-032306-0100		GUARD SCREEN	
000-032308-0000		COIL, AS-703/704, 90V	
000-032416-0000		GUARD SCREEN	
000-054686-0000		JUNCTION BOX	
0DY-012814-0000		BALL BEARING, SR, W/ONE SHIELD, 209	
AS-704	000-018973-0000	ACTUATOR SPRING	
	000-032296-0000	BRAKE FAN	
	000-032297-0000	BRAKE ROTOR	
	000-032303-0000	SHAFT, AS-704	
	000-032306-0200	GUARD SCREEN	
	000-032308-0000	COIL, AS-703/704, 90V	
	000-032416-0000	GUARD SCREEN	
	000-054686-0000	JUNCTION BOX	
	0DY-012814-0000	BALL BEARING, SR, W/ONE SHIELD, 209	
AS-705	000-018973-0000	ACTUATOR SPRING	
	000-027379-0100	BRAKE ROTOR	
	000-032283-0000	BRAKE FAN	
	000-032284-0000	SHAFT, AS-705	
	000-032306-0300	GUARD SCREEN	
	000-032501-0000	GUARD SCREEN	
	000-033533-0000	COIL, AS-705/706, 90V	
	000-054686-0000	JUNCTION BOX	
	0DY-000196-0000	BALL BEARING, SR, W/ONE SHIELD, 211	
AS-706	000-027379-0100	BRAKE ROTOR	
	000-032283-0000	BRAKE FAN	
	000-032306-0400	GUARD SCREEN	
	000-032316-0000	SHAFT, AS-706	
	000-032501-0000	GUARD SCREEN	
	000-033533-0000	COIL, AS-705/706, 90V	
	000-054686-0000	JUNCTION BOX	
	0DY-000196-0000	BALL BEARING, SR, W/ONE SHIELD, 211	
AS-707	000-018973-0000	ACTUATOR SPRING	
	000-032306-0500	GUARD SCREEN	
	000-036608-0000	SCREEN COVER	

MODEL	PART NUMBER	DESCRIPTION
AS-707 CONT'D.	000-036616-0000	SHAFT, AS-707
	000-036618-0000	BRAKE ROTOR
	000-036619-0000	BRAKE FAN
	000-046832-0000	COIL, AS-707/708, 90V
	0DY-005001-0000	BALL BEARING, SR, W/ONE SHIELD, 316
AS-708	000-018973-0000	ACTUATOR SPRING
	000-036608-0000	SCREEN COVER
	000-036618-0000	BRAKE ROTOR
	000-036619-0000	BRAKE FAN
	000-036623-0000	SHAFT, AS-708
	000-046832-0000	COIL, AS-707/708, 90V
	0DY-005001-0000	BALL BEARING, SR, W/ONE SHIELD, 316
WC-620	000-030791-0045	CANNED COIL ASSY, 620
WC-620	000-030791-0090	CANNED COIL ASSY, 620
WC-620	000-030794-0045	FIELD ASSY, WB-620
WC-620	000-030794-0090	FIELD ASSY, WB-620
WC-620	000-040923-0000	COIL SPACER
WC-620	000-060077-0100	GENERATOR ROTOR, WB-620
WC-620	000-060078-0100	GENERATOR FIELD ASSY, WB-620
WC-620	0DY-000698-0000	BEARING, CARTRIDGE, WITH SNAP RING, 6208
WC-620	0DY-010949-0000	BEARING, CARTRIDGE, 208
WC-620/630	0DY-013844-0000	SOLENOID VALVE, 3/8" NPT
WC-620/640	000-065491-0100	JUNCTION BOX
WC-630	000-031519-0045	CANNED COIL ASSY, 630
WC-630	000-031519-0110	CANNED COIL ASSY, 630
WC-630	000-065469-0100	GENERATOR ROTOR, WB-630
WC-630	000-065470-0100	GENERATOR FIELD ASSY, WB-630
WC-630/640	0DY-000116-0000	BEARING, CARTRIDGE, W/SNAP RG, 2SHLDS, 309
WC-630/640	0DY-000117-0000	BEARING, CARTRIDGE, 2 SHIELDS, 309
WC-640	000-030758-0045	CANNED COIL ASSY, 640
WC-640	000-030758-0090	CANNED COIL ASSY, 640
WC-640	000-030758-0220	CANNED COIL ASSY, 640
WC-640	000-031188-0045	FIELD ASSY, WB-640
WC-640	000-031188-0090	FIELD ASSY, WB-640
WC-640	000-031188-0220	FIELD ASSY, WB-640
WC-640	000-050016-0000	GENERATOR LAMINATION & COIL ASSY
WC-640	000-051175-0000	GENERATOR ROTOR, WB-640
G-2	000-032642-0100	GENERATOR ROTOR ASSY, G-2
	000-060452-0100	BEARING & SHAFT, G-2
	000-088470-0100	GENERATOR ASSY, G-2

MODEL	PART NUMBER	DESCRIPTION
MISCELLANEOUS	000-000244-0100	BRUSH
	000-000244-0700	BRUSH
	000-025041-0000	BRUSH, CARBON
	000-040923-0000	COIL SPACER
	000-040923-0100	COIL SPACER
	000-040923-1000	COIL SPACER
	000-065300-0300	BLOWER MOTOR
	000-072886-0175	TEMPERATURE SWITCH, N.O.
	0DY-001892-0000	CLIP, JIFFY
	0DY-009527-0000	BEARING, CARTRIDGE, W/2 SEALS, 1 SNAPRING
	0DY-010419-0000	PRESSURE SWITCH
	0DY-011943-0000	TEMPERATURE SWITCH, N.C.
	0DY-011944-0000	TEMPERATURE SWITCH, N.O.
	0DY-012659-0000	BEARING, CARTRIDGE, 3511
	0DY-013450-0000	STEP SEAL RING
	0DY-016669-0000	BEARING, SPHERICAL ROLLER, 22312
CES MECH.		
37-21	000-031528-0000	SLIP RING ASSY
37-21	000-034973-0000	BRUSH RIGGING ASSY
37-21	000-035017-0100	SHAFT
37-21	000-047717-0000	BEARING CAP & SLIP RING ASSY
37-21	000-053486-0000	SLIP RING HARNESS ASSY
37-21	000-061720-0400	PEDESTAL TIE BAR ASSY
37-21	000-062840-0100	BRAKE FIELD & RING ASSY
37-21	000-063846-0300	THYRITE & SUPPORT ASSY
37-21	000-064193-0200	CLUTCH FIELD & BELT RING ASSY
37-21	000-086690-0100	BEARING CAP & PICK-UP ASSY
37-21	000-086708-0100	BRAKE ROTOR ASSY
37-21/37-32	000-063706-0200	SHAFT END GUARD
37-21/37-42	000-076890-0100	CLUTCH ROTOR ASSY
37-21/37-42	0DY-005721-0000	BEARING, CYLINDRICAL ROLLER, SPL.
37-21/37-42	0DY-005723-0000	BEARING, SPHERICAL ROLLER, 23136
37-21/37-42	0DY-005789-0000	BEARING, SPHERICAL ROLLER, 23038
37-21/49-63	000-000244-0000	BRUSH
37-32	000-030459-0000	SLIP RING SEPARATOR
37-32	000-030470-0000	CLUTCH ROTOR ASSY
37-32	000-034922-0000	BRUSH HOLDER BRACKET
37-32	000-035010-0000	SHAFT
37-32	000-061720-0500	PEDESTAL TIE BAR ASSY
37-32	000-065459-0100	CLUTCH FIELD & BELT RING ASSY
37-32/37-42	000-028735-0100	BRUSH HOLDER
37-32/37-42	000-030462-0000	SLIP RING ASSY
37-32/37-42	000-034747-0000	BRAKE ROTOR ASSY
37-32/37-42	000-047718-0000	BEARING CAP & SLIP RING ASSY
37-32/37-42	000-053485-0001	SLIP RING HARNESS ASSY
37-32/37-42	000-057591-0100	BRAKE SHOE
37-32/37-42	000-062958-0100	BRAKE FIELD & RING ASSY
37-32/37-42	000-063636-0100	GENERATOR ROTOR ASSY, CES
37-32/37-42	000-063641-0100	BEARING CAP & FIELD ASSY
37-32/37-42	000-063846-0200	THYRITE & SUPPORT ASSY
37-32/37-42	000-073400-0100	BRAKE SHOE ASSY, 37"
37-32/37-42	000-073402-0100	BRAKE SHOE ASSY, 37"
37-32/49-63	000-034974-0000	BRUSH RIGGING ASSY
37-42	000-031360-0000	CLUTCH FIELD & BELT RING ASSY
37-42	000-031386-0000	SHAFT
37-42	000-059061-0100	SHAFT END GUARD
37-42	000-061720-0600	PEDESTAL TIE BAR ASSY
49-42	000-030628-0100	GASKET
49-42	000-030631-0100	GASKET
49-42	000-034017-0000	BEARING CAP
49-42	000-034020-0100	CLUTCH FIELD & BELT RING ASSY

MODEL	PART NUMBER	DESCRIPTION
49-42	000-034023-0000	CLUTCH ROTOR ASSY
49-42	000-034036-0000	SPACER
49-42	000-034453-0000	BRAKE ROTOR ASSY
49-42	000-034454-0000	PEDESTAL BEARING CAP
49-42	000-035153-0000	SHAFT
49-42	000-057590-0100	BRAKE SHOE
49-42	000-061270-0200	BRAKE FIELD & RING ASSY
49-42	000-061720-0700	PEDESTAL TIE BAR ASSY
49-42	000-063386-0100	SHAFT END GUARD
49-42	000-063387-0100	PRESS DRIVE GENERATOR ASSY, LONG SHAFT
49-42	000-063846-0100	THYRITE & SUPPORT ASSY
49-42	000-069226-0100	OIL CATCHER
49-42	0DY-006912-0000	BEARING, SPHERICAL ROLLER, 23044
49-42/49-63	000-034030-0000	SLIP RING ASSY
49-42/49-63	000-034031-0100	SLIP RING
49-42/49-63	000-047716-0000	BEARING CAP & SLIP RING ASSY
49-42/49-63	000-063383-0100	GENERATOR ROTOR ASSY, 49"
49-42/49-63	000-064172-0100	SLIP RING HARNESS ASSY
49-42/49-63	000-072701-0100	SHOE BRAKE ASSY
49-42/49-63	0DY-006910-0000	BEARING, CYLINDRICAL ROLLER, 5142
49-42/49-63	0DY-006911-0000	BEARING, SPHERICAL ROLLER, 23140
49-63	000-063385-0100	BEARING CAP ASSY
49-63	000-063597-0100	SHAFT END GUARD
49-63	000-063817-0100	SHAFT
49-63	000-063820-0100	CLUTCH ROTOR ASSY
49-63	000-063821-0100	BRAKE ROTOR ASSY
49-63	000-063838-0100	CLUTCH FIELD & BELT RING ASSY
49-63	000-063838-0200	CLUTCH FIELD & BELT RING ASSY
49-63	000-063838-0300	CLUTCH FIELD & BELT RING ASSY
49-63	000-063839-0100	BRAKE FIELD & RING ASSY
49-63	000-063846-0400	THYRITE & SUPPORT ASSY
49-63	000-063917-0100	PEDESTAL TIE BAR ASSY
49-63	0DY-014475-0000	BEARING, SPHERICAL ROLLER, 23148
49-63	0DY-014476-0000	BEARING, SPHERICAL ROLLER, 23052
SPM,SPC,SPMV		
8100, 1	000-047183-0100	GENERATOR FIELD ASSY, 8100, 1
8100, 1	000-048557-0000	GENERATOR ROTOR, 8100, 1
8100, 1	000-070692-0100	SLIP RING ASSY
8100, 1	0DY-004799-0000	BALL BEARING, SR, 310
8100, 1	0DY-014924-0000	BEARING KIT
8100/8220	000-000244-0000	BRUSH
8100/8220	000-014175-0000	BRUSH HOLDER
8120, 1	000-043001-0500	GENERATOR ROTOR, 8120, 1
8120, 1	000-043087-0000	GENERATOR FIELD ASSY, 8120, 1
8120, 1	0DY-003764-0000	BALL BEARING, SR, 313
8120, 1	0DY-015189-0000	BEARING, SR, ANGULAR CONTACT
8140, 1	000-062130-0100	GENERATOR ROTOR, 8140, 1
8140, 1	000-066991-0100	GENERATOR FIELD ASSY, 8140, 1
8140, 1	0DY-004619-0000	BALL BEARING, SR, 318
8140, 1	0DY-015324-0000	BEARING, ANGULAR CONTACT (2)318
8160, 1	000-067736-0100	GENERATOR ROTOR, 8160, 1
8160, 1	000-071119-0100	GENERATOR FIELD ASSY, 8160, 1
8160, 1	0DY-006699-0000	BALL BEARING, SR, 320
8180, 1	000-067736-0100	GENERATOR ROTOR, 8160, 1
8180, 1	000-067737-0100	GENERATOR FIELD ASSY, 8180, 1
8180, 1	0DY-003261-0000	BALL BEARING, SR, 322
8180, 1	0DY-014981-0000	BEARING, CYLINDRICAL ROLLER
8200, 1	000-068346-0100	GENERATOR ROTOR, 8200, 1
8200, 1	000-070980-0100	SLIP RING & SEAL ASSY
8200, 1	0DY-011475-0000	BALL BEARING, SR, 324
8200, 1	0DY-014981-0000	BEARING, CYLINDRICAL ROLLER

MODEL	PART NUMBER	DESCRIPTION
8220, 1	000-067939-0100	GENERATOR FIELD ASSY, 8220, 1
8220, 1	000-067959-0100	GENERATOR ROTOR, 8220, 1
8220, 1	000-070445-0100	SLIP RING ASSY
8220, 1	0DY-014980-0000	BALL BEARING, SR, 326
CANNED COILS		
WC-206	000-072620-0045	CANNED COIL ASSY, 206
WC-208	000-049887-0045	CANNED COIL ASSY, 208B
WC-210	000-054275-0045	CANNED COIL ASSY, 210
WC-210	000-054275-0090	CANNED COIL ASSY, 210
WC-210	000-036863-0045	CANNED COIL ASSY, 210B
WC-212	000-049878-0045	CANNED COIL ASSY, 212
WC-212	000-049878-0110	CANNED COIL ASSY, 212
WC-212	000-049878-0220	CANNED COIL ASSY, 212
WC-212	000-049878-1045	CANNED COIL ASSY, 212
WC-212	000-049878-1220	CANNED COIL ASSY, 212
WC-212	000-062734-0045	CANNED COIL ASSY, 212
WC-212	000-062734-0090	CANNED COIL ASSY, 212
WC-212	000-062734-0220	CANNED COIL ASSY, 212
WC-212	000-036728-1045	CANNED COIL ASSY, 212B
WCS-214	000-049724-0045	CANNED COIL ASSY, 214
WC-214	000-062162-0045	CANNED COIL ASSY, 214
WC-214	000-062162-0090	CANNED COIL ASSY, 214
WC-214	000-062162-0220	CANNED COIL ASSY, 214
WCS-214	000-037019-0045	CANNED COIL ASSY, 214B
WCS-215	000-038144-0045	CANNED COIL ASSY, 215
WCS-215	000-038144-0090	CANNED COIL ASSY, 215
WCS-215	000-038144-0230	CANNED COIL ASSY, 215
WCS-216	000-041271-0045	CANNED COIL ASSY, 216
WCS-216	000-041271-0090	CANNED COIL ASSY, 216
WCS-216	000-041271-0220	CANNED COIL ASSY, 216
WCS-216	000-052402-1045	CANNED COIL ASSY, 216
WCS-216	000-052402-1090	CANNED COIL ASSY, 216
WCS-216	000-052402-1220	CANNED COIL ASSY, 216
WCS-216	000-052402-2045	CANNED COIL ASSY, 216
WCS-216	000-052402-2090	CANNED COIL ASSY, 216
WCS-216	000-052402-2220	CANNED COIL ASSY, 216
WCS-216	000-041299-1045	CANNED COIL ASSY, 216B
WCS-217	000-051249-1045	CANNED COIL ASSY, 217
WCS-217	000-051249-2045	CANNED COIL ASSY, 217
WCS-218	000-034157-0045	CANNED COIL ASSY, 218
WCS-218	000-037697-0220	CANNED COIL ASSY, 218
WCS-219	000-048688-0100	CANNED COIL ASSY, 219
WCS-219	000-050046-0045	CANNED COIL ASSY, 219
WCS-219	000-050046-0090	CANNED COIL ASSY, 219
WCS-219	000-050046-0150	CANNED COIL ASSY, 219
WCS-219	000-050046-0220	CANNED COIL ASSY, 219
WCS-220	000-034157-0090	CANNED COIL ASSY, 220
WCS-220	000-034157-0220	CANNED COIL ASSY, 220
WCS-221	000-050046-1090	CANNED COIL ASSY, 221
WCS-221	000-050046-1220	CANNED COIL ASSY, 221
WCS-223	000-079736-0100	CANNED COIL ASSY, 223
WCS-223	000-079736-0200	CANNED COIL ASSY, 223B
WCS-224	000-034352-0000	CANNED COIL ASSY, 224
WCS-224	000-042779-0000	CANNED COIL ASSY, 224
WCS-225	000-052754-0090	CANNED COIL ASSY, 225
WCS-225	000-052754-0220	CANNED COIL ASSY, 225
WCS-225	000-061594-0090	CANNED COIL ASSY, 225
WCS-227	000-059021-0090	CANNED COIL ASSY, 227
WCS-228	000-038028-0000	CANNED COIL ASSY, 228
WCS-228	000-050578-0000	CANNED COIL ASSY, 228
WCS-230	000-045023-0000	CANNED COIL ASSY, 230

MODEL	PART NUMBER	DESCRIPTION
WCS-230	000-051773-0000	CANNED COIL ASSY, 230
WC-620	000-030791-0045	CANNED COIL ASSY, 620
WC-620	000-030791-0090	CANNED COIL ASSY, 620
WC-630	000-031519-0045	CANNED COIL ASSY, 630
WC-630	000-031519-0110	CANNED COIL ASSY, 630
WC-640	000-030758-0045	CANNED COIL ASSY, 640
WC-640	000-030758-0090	CANNED COIL ASSY, 640
WC-640	000-030758-0220	CANNED COIL ASSY, 640
AC-181/186	000-074167-0100	COVER
AC-181/186	0DY-000755-0000	BALL BEARING, SR, W/2 SEALS, 307
AC-181/186	0DY-010949-0000	BEARING, CARTRIDGE, 208
AC-181/216	000-053570-0100	JUNCTION BOX BASE
AC-181/216	000-053571-0100	JUNCTION BOX COVER
AC-181/216	000-055678-0100	GASKET, CONDUIT BOX
AC-181/256	000-040045-0100	GASKET, CONDUIT BOX
AC-181/256	000-049852-0100	GENERATOR LAMINATION & COIL ASSY
AC-181/256	000-071678-0200	GENERATOR ROTOR, 181-256
AC-181/256	000-073346-0101	BRUSH HOLDER
AC-181/256	000-073346-0102	BRUSH HOLDER CAP
AC-181/256	000-073520-0100	BRUSH
AC-181/256	0DY-007335-0000	BALL BEARING, SR, W/ONE SEAL, 210
AC-181/256	0DY-007336-0000	BALL BEARING, SR, W/ONE SEAL, 307
AC-181/256	0DY-015335-0000	RETAINING RING, EXTERNAL, 1-1/4"
AC-181/256	0DY-015911-0000	WAVE SPRING, 3.50 O.D. X 3.00 I.D.
AC-214, 216	0DY-012815-0000	BEARING, CARTRIDGE, 3509
AC-214, 216	0DY-014821-0000	BALL BEARING, SR, W/2 SEALS, 308
AC-214/216	000-073469-0045	COIL, 214/216, 45V
AC-254, 256	000-055757-0100	GASKET, CONDUIT BOX
AC-254, 256	040-053371-0200	JUNCTION BOX COVER
AC-254, 256	0DY-000942-0000	BEARING, CARTRIDGE, W/2 SEALS, 210
AC-254, 256	0DY-004909-0000	BALL BEARING, 6309
ACM-902	000-048168-0000	WAVE WASHER, 902
ACM-902	000-048173-0100	GENERATOR ROTOR, 902
ACM-902	000-049852-0100	GENERATOR LAMINATION & COIL ASSY
ACM-902	0DY-004806-0000	BEARING, CARTRIDGE, 206
ACM-902	0DY-009265-0000	BALL BEARING, SR, W/ONE SEAL, 108
ACM-902	0DY-010408-0000	SPRING, ADJUSTABLE
ACM-902/904	000-053570-0100	CONDUIT BOX BASE
ACM-902/904	000-053571-0100	CONDUIT BOX COVER
ACM-902/904	000-055678-0100	GASKET, CONDUIT BOX
ACM-903	000-042093-0100	GENERATOR ROTOR, 903
ACM-903	000-057427-0100	GENERATOR FIELD ASSY, 9033
ACM-903	0DY-003783-0000	RETAINING RING, EXTERNAL, 1-9/16"
ACM-903	0DY-004004-0000	BALL BEARING, SR, W/ONE SHIELD, 307
ACM-903	0DY-004005-0000	BALL BEARING, SR, W/ONE SHIELD, 208
ACM-903	0DY-010422-0000	BALL BEARING, SR, 205
ACM-903	0DY-010949-0000	BEARING, CARTRIDGE, 208
ACM-903/905	000-040045-0100	GASKET
ACM-904	000-057336-0100	GENERATOR ROTOR, 904
ACM-904	000-057337-0100	GENERATOR FIELD ASSY, 9043
ACM-904	0DY-005818-0000	RETAINING RING, EXTERNAL, 45 MM
ACM-904	0DY-010423-0000	BALL BEARING, SR, 305
ACM-904	0DY-011398-0000	BALL BEARING, SR, W/ONE SHIELD, 308
ACM-904	0DY-012814-0000	BALL BEARING, SR, W/ONE SHIELD, 209
ACM-904	0DY-012815-0000	BEARING, CARTRIDGE, 3509
ACM-905	000-046095-0000	BEARING INSUL SHIELD WSHR
ACM-905	000-048453-0200	BEARING DUST SHIELD
ACM-905	000-048472-0000	GENERATOR FIELD ASSY, 9053
ACM-905	000-048474-0100	GENERATOR ROTOR, 905
ACM-905	000-055757-0100	GASKET, CONDUIT BOX

MODEL	PART NUMBER	DESCRIPTION
ACM-905	040-053371-0200	CONDUIT BOX COVER
ACM-905	0DY-000942-0000	BEARING, CARTRIDGE, W/2 SEALS, 210
ACM-905	0DY-003163-0000	BALL BEARING, SR, W/ONE SHIELD, 210
ACM-905	0DY-007656-0000	BALL BEARING, SR, 306
ACM-905	0DY-010941-0000	RETAINING RING, EXTERNAL, 50 MM
ACM-906	000-054378-0100	GENERATOR ROTOR, 906/206
ACM-906	000-054381-0100	GENERATOR FIELD ASSY, 906
ACM-906	0DY-009265-0000	BALL BEARING, SR, W/ONE SEAL, 108
ACM-906	0DY-011398-0000	BALL BEARING, SR, W/ONE SHIELD, 308
ACM-908	000-047183-0200	GENERATOR FIELD ASSY, 908/208
ACM-908	000-047539-0000	GENERATOR ROTOR, 908/208
ACM-908	000-053283-0600	BEARING GUIDE
ACM-908	000-053284-0600	SHRINK RING, 908
ACM-908	000-056032-0100	GREASE & WATER SEAL
ACM-908	0DY-013139-0000	BEARING, CYLINDRICAL ROLLER, 211
ACM-908/910	000-048842-0000	GENERATOR FIELD ASSY, 908-9103
ACM-908/910	000-053373-0100	GENERATOR ROTOR, 908/910
ACM-910	000-047183-0100	GENERATOR FIELD ASSY, 908/910
ACM-910	000-048557-0000	GENERATOR ROTOR, 910
ACM-910	000-053283-0400	BEARING GUIDE
ACM-910	000-053284-0400	SHRINK RING, 910
ACM-910	000-055991-0100	GREASE & WATER SEAL
ACM-910	0DY-004783-0000	BALL BEARING, SR, W/ONE SHIELD, 310
ACM-910	0DY-011875-0000	BEARING, CYLINDRICAL ROLLER, 212
ACM-912	000-043001-0400	GENERATOR ROTOR, 912/212
ACM-912	000-043063-0000	GENERATOR FIELD ASSY, 912/212
ACM-912	000-047309-0000	COIL, 912, 90V
ACM-912	000-052495-0000	GREASE & WATER SEAL
ACM-912	000-053283-0100	BEARING GUIDE
ACM-912	000-053284-0100	SHRINK RING, 912
ACM-912	0DY-009709-0000	BALL BEARING, SR, W/ONE SHIELD, 312
ACM-912	0DY-011881-0000	BEARING, CYLINDRICAL ROLLER, 213
ACM-914	000-043001-0500	GENERATOR ROTOR, 914
ACM-914	000-043087-0000	GENERATOR FIELD ASSY, 912/212
ACM-914	000-052635-0000	GREASE & WATER SEAL
ACM-914	000-053283-0200	BEARING GUIDE
ACM-914	000-053284-0200	SHRINK RING, 914
ACM-914	0DY-007377-0000	BALL BEARING, SR, W/ONE SHIELD, 313
ACM-914	0DY-009408-0000	BEARING, CYLINDRICAL ROLLER, 215
EC-14	000-081022-0100	END COVER, AS-14
EC-14	0DY-012646-0000	BALL BEARING, W/ONE SEAL, 305
EC-14	0DY-013193-0000	BALL BEARING, W/ONE SEAL, 208
EC-14	0DY-013282-0000	BALL BEARING, W/ONE SHIELD, 206
EC-14	0DY-015784-0000	WAVE SPRING, 3.12 O.D. X 2.73 I.D.
EC-14	0DY-016398-0000	OIL SEAL, 40 MM DIA. SHAFT
EC-14/18	0DY-016449-0000	BALL BEARING, SR, ONE SHIELD, 6306
EC-14/25	000-040045-0100	GASKET
EC-14/25	000-053570-0100	JUNCTION BOX BASE
EC-14/25	000-053571-0100	JUNCTION BOX COVER
EC-14/25	000-081047-0100	BRUSH ASSY
EC-18	0DY-011332-0000	BALL BEARING, SR, W/ONE SHIELD, 306
EC-18	0DY-013266-0000	BALL BEARING, SR, W/ONE SHIELD, 207
EC-18	0DY-016400-0000	OIL SEAL, 45 MM DIA. SHAFT
EC-18/21	0DY-007273-0000	BALL BEARING, SR, W/ONE SEAL, 211
EC-18/21	0DY-016588-0000	WAVE SPRING, 3.87 O.D. X 3.37 I.D.
EC-18/25	000-082022-0200	END COVER, AS-18-25
EC-21	0DY-003634-0000	BALL BEARING, W/ONE SHIELD, 209
EC-21	0DY-007336-0000	BALL BEARING, SR, W/ONE SEAL, 307
EC-21	0DY-016402-0000	OIL SEAL, 55 MM DIA. SHAFT
EC-21/25	0DY-015621-0000	BALL BEARING, SR, W/ONE SHIELD, 309
EC-25	0DY-009263-0000	BALL BEARING, SR, W/ONE SEAL, 212

MODEL	PART NUMBER	DESCRIPTION
EC-25	0DY-010237-0000	BALL BEARING, SR, W/ONE SHIELD, 309
EC-25	0DY-013574-0000	BALL BEARING, SR, W/ONE SHIELD, 210
EC-25	0DY-016471-0000	OIL SEAL, 62 MM DIA. SHAFT
EC-25	0DY-016589-0000	WAVE SPRING, 4.25 O.D. X 3.74 I.D.
280	000-053284-1100	SHRINK RING, AS-280
280	000-077948-0100	GENERATOR FIELD ASSY, 280
280	000-078083-0100	GENERATOR ROTOR, 280
280	000-078586-0045	COIL, 280 SF, 45V
280	000-078586-0090	COIL, 280 SF, 90V
280	000-078586-0110	COIL, 280 SF, 110V
280	000-078586-1045	COIL, 280 SF, 45V
280	000-078586-1090	COIL, 280 SF, 90V
280	000-078642-0100	JUNCTION BOX COVER
280	000-078643-0100	GASKET
280	000-085205-0045	COIL, 280 SF, 45V
280	000-085205-0045	COIL, 280 SF, 45V
280	000-085205-0090	COIL, 280 SF, 90V
280	000-085205-0220	COIL, 280 SF, 220V
280	000-085669-0100	GENERATOR FIELD ASSY, AS-280
280	0DY-001663-0000	BEARING, SPHERICAL ROLLER22310
280	0DY-004783-0000	BALL BEARING, SR, W/ONE SHIELD, 310
280	0DY-009920-0000	BALL BEARING, SR, 211
280	0DY-016089-0000	GREASE SEAL
280	0DY-016170-0000	BEARING, CYLINDRICAL ROLLER, 211
320	000-053284-0900	SHRINK RING, AS-320
320	000-078445-0045	COIL, 320 RF, 45V
320	000-078445-1045	COIL, 320 RF, 45V
320	000-078445-1090	COIL, 320 RF, 90V
320	000-078522-0100	GENERATOR ROTOR, 320
320	000-078522-0200	GENERATOR ROTOR, 320
320	000-078524-0100	JUNCTION BOX COVER
320	000-078525-0100	GASKET
320	000-080922-0100	SLIP RING ASSY
320	000-085173-0045	COIL, 320 SF, 45V
320	000-085173-0090	COIL, 320 SF, 90V
320	000-085173-1090	COIL, 320 SF, 90V
320	000-085669-0200	GENERATOR FIELD ASSY, 320
320	000-085669-0300	GENERATOR FIELD ASSY, 320SFB
320	000-087395-0100	SHAFT, AS-320
320	0DY-001586-0000	BALL BEARING, 6212
320	0DY-009709-0000	BALL BEARING, SR, W/ONE SHIELD, 312
320	0DY-011532-0000	BEARING, SPHERICAL ROLLER22312
320	0DY-016085-0000	BALL BEARING, SR, W/2 SHIELDS, 312
320	0DY-016087-0000	GREASE SEAL
320	0DY-016448-0000	BEARING, CYLINDRICAL ROLLER, 212
360	000-053284-1000	SHRINK RING, AS-360
360	000-078577-0045	COIL, 360 SF, 45V
360	000-078577-0090	COIL, 360 SF, 90V
360	000-078593-0100	GASKET
360	000-078934-0200	GENERATOR FIELD ASSY, 360
360	000-079001-0100	SPACER
360	000-085179-0045	COIL, 360 SF, 45V
360	000-085179-0090	COIL, 360 SF, 90V
360	000-085179-1045	COIL, 360 SF, 45V
360	0DY-005198-0000	BEARING, SPHERICAL ROLLER22313
360	0DY-006026-0000	BALL BEARING, SR, 215
360	0DY-016148-0000	GREASE SEAL
360	0DY-016172-0000	BEARING, CYLINDRICAL ROLLER, 215
360	0DY-016193-0000	SEAL RING
440	000-053284-1200	SHRINK RING, AS-440
440	000-060997-0400	BEARING SPACER

MODEL	PART NUMBER	DESCRIPTION
440	000-078666-0045	COIL, 440 RF, 45V
440	000-078666-0090	COIL, 440 RF, 90V
440	000-078666-0220	COIL, 440 RF, 220V
440	000-078666-1045	COIL, 440 RF, 45V
440	000-078666-1090	COIL, 440 RF, 90V
440	000-078934-0100	GENERATOR FIELD ASSY, AS-440
440	000-085498-0100	BEARING SLEEVE
440	0DY-001079-0000	BALL BEARING, 6218
440	0DY-015862-0000	BEARING, CYLINDRICAL ROLLER, 218
440	0DY-016160-0000	GREASE SEAL
440	0DY-016670-0000	BEARING, SPHERICAL ROLLER, 22318
280/320	000-085669-0400	GENERATOR FIELD ASSY, 280/320
280/440	000-078559-0100	BRUSH, W/PIG TAIL
280/440	000-078560-0100	BRUSH HOLDER
280/440	000-080175-0100	BRUSH HOLDER STUD
280-440	000-078559-0400	BRUSH

MODEL	PART NUMBER	DESCRIPTION
-------	-------------	-------------

MODEL	PART NUMBER	DESCRIPTION
-------	-------------	-------------

DRIVE SOURCE INTERNATIONAL, INC.

7900 Durand Avenue, P.O. Box 0361

Sturtevant, WI USA 53177

Toll Free: (800) 548-2169

Phone: (262) 554-7977 - Fax: (262) 554- 7041

Email: sales@drivesourceusa.com